03900-BS200 A0

| GENERAL TOLERANCE | | | |
|---|---|---|---|
| DIM | | ANGLE | |
| 1 ~ 6 | ±0.1 | 0 ~ 10 | ±1° |
| 6 ~ 30 | ±0.2 | 10 ~ 50 | ±0.5° |
| 30 ~ 120 | ±0.3 | 50 ~ 120 | ±0.3° |
| 120 ~ 400 | ±0.5 | 120 ~ 400 | ±0.1° |
| 400 ~ 1000 | ±1.0 | | |

| No | DATE | REVISION | ED NUMBER |
|---|---|---|---|
| 1 | 20140514 | RELEASED | HSW-2014-053 |










FLANGE SPEC. : DIN ISO 7646-DESIGN B




① SEAWATER PUMP
② INTERCOOLER
③ HEAT EXCHANGER
④ POWER STEERING & GEARBOX OIL COOLER
⑤ ECU CASE WITH ENGINE CONTROL UNIT & RELAY ASSY
⑥ COOLANT EXPANSION TANK
⑦ POWER STEERING OIL RSV.TANK
⑧ FUEL FILTER
⑨ FUEL PUMP FROM FUEL TANK(LOW PRESSURE) : Φ8mm
⑩ ELECTRIC ENGINE OIL DRAIN PUMP
⑪ BRACKET FOR SHIFTING POSITION
⑫ EMERGENCY ENGINE STOP SWITCH
⑬ SEAWATER HOSE CONNECTION : Φ46mm
⑭ ACCEL POSITION SENSOR WITH THROTTLE CABLE CONNECTION
⑮ ENGINE OIL LEVEL GAUGE

NOTES
1.치수 따지 말 것. (DO NOT SCALE)

| QTY | QTY | No. | PART No. | PART NAME | MTRL | REMARK |
|---|---|---|---|---|---|---|
| | | | | | | |

현 대 씨 즐 주 식 회 사
HYUNDAI SEASALL Co.

| | | | |
|---|---|---|---|
| CY.KIM | | 1/3 | 눈금따지 말것 DO NOT SCALE |
| MATERIAL | --- | | |
| FINISH | --- | .00 | |

PART NAME
S270J-BEARING HOUSING 인스톨 도면
S270J-BEARING HOUSING INSTALLATION DRAWING
PART NO 03900-BS200 A0 1/1

HS-QMP-06-10 REV.2